OEL Recommended Spare Parts List

C7200/C7400

Revision 11

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000			
	Main Assy	1	40864601	Cover Assy.-Front	1	3	6	12			
	Main Assy	2	41042501	Guide-Sheet(Bottom)	1	3	6	12			
	Main Assy	3	40866701	Cassette Assy	1	3	6	12			
	Main Assy	4	41438401	Frame Assy.-Separation	1	3	6	12			
	Main Assy	6	40864301	Cover-Rear	1	3	6	12			
	Main Assy	7	41374902	Stacker Assy.-F UP	1	3	6	12			
	Main Assy	8	40864401	Cover-Side(L)	1	3	6	12			
	Main Assy	9	40864501	Cover-Side(R)	1	3	6	12			
	Main Assy	10	40862001	Feeder Assy.-Front	1	3	6	12			
	Main Assy	11	40866301	Cover-Assy FF	1	3	6	12			
	Main Assy	12	41045801	Stay-Links	2	6	12	24			
	Main Assy	13	40325101	Gear-z68	1	3	6	12			
	Main Assy	14	40952701	Frame-Top	1	3	6	12			
	Main Assy	18	41256204	Board-71K	1	3	6	12	1200dpi		
	Main Assy	18	41256206	Board-71K	1	3	6	12	600dpi		
	Main Assy	19	40197102	Motor-Fan(CU)	1	3	6	12	ECO-C7400-		
	Main Assy	20	40864901	Frame Assy.-Release	1	3	6	12			
	Main Assy	21	41275701	Microswitch-Assy	1	3	6	12			
	Main Assy	22	41439401	Spring-Separation	2	6	12	24			
	Main Assy	26	816A2323M0000	NM93C66N-NW	1	3	6	12			
	Main Assy	34	41377401	Plate-Indicator	1	3	6	12			
	Main Assy	35	41716809	Board- SWA	1	3	6	12			
	Main Assy	36	8164323M0000	M93C86-WBN6P	1	3	6	12			
	Main Assy	37	41469503	Board-TNY	1	3	6	12			
	Main Assy	43	41848501	Cover Assy.-CU(Maintenance)	1	3	6	12			
	Main Assy	44	41278601	Guide-Rail(A)	1	3	6	12	ECO-C7400-		
	Main Assy	45	41278701	Guide-Rail(B)	1	3	6	12			
	Main Assy	46	41410201	Motor-Fan	1	3	6	12			
	Main Assy	47	41467401	Plate-FG(Centoro)	1	3	6	12			
	Main Assy	48	41254601	Plate-Blank	1	3	6	12	ECO-C7400-		
	Main Assy	49	41723901	Screw-Knob	1	-	-	-	ECO-C7400-		
	Main Assy	50	41723901	Screw-Knob	2	-	-	-			
	Main Assy	51	LB-102100-2A	Collar	1	-	-	-	ECO-C7400-		
	Toop Cover Assembly	1	40859701	Cover-Stacker	1	3	6	12			
	Toop Cover Assembly	2	41072401	Holder Assy.-Head	4	12	24	48			
	Toop Cover Assembly	-	41072402	Holder Assy.-Head	4	12	24	48			
	Toop Cover Assembly	3	40861001	Spring-Head	8	24	48	96			
	Toop Cover Assembly	4	41257901	Board-Y71	1	3	6	12			
	Toop Cover Assembly	5	40365404	SENSOR-Stack Full	1	3	6	12			
	Toop Cover Assembly	6	41316501	Cover Assy.-Inner(Sub)	1	3	6	12			
	Toop Cover Assembly	7	41309603	Cable Assy.-Head(M)	1	3	6	12			
	Toop Cover Assembly	8	41309604	Cable Assy.-Head(C)	1	3	6	12			
	Toop Cover Assembly	9	41309602	Cable Assy.-Head(Y)	1	3	6	12			
	Toop Cover Assembly	10	41309601	Cable Assy.-Head(K)	1	3	6	12			
	Toop Cover Assembly	11	41593101	Cable Assy.-POW	1	3	6	12			
	Toop Cover Assembly	14	41765601	Roller-Idle(FD)	8	3	6	12	ECO-C7400-		
	Toop Cover Assembly	15	40860601	Sensor Assy.-Toner	4	3	6	12			
	Toop Cover Assembly	16	40866101	Frame Assy.-OP Panel	1	3	6	12			
	Toop Cover Assembly	17	40866201	Plate-OP Panel	1	3	6	12	600dpi		
	Toop Cover Assembly	17	40866202	Plate-OP Panel	1	3	6	12	1200dpi		
	Toop Cover Assembly	18	2381003P0014	HCUJ/TW-VFM/6F-150	1	3	6	12	ECO-C7400-		
	Toop Cover Assembly	19	40861501	Guide Assy.-Eject	1	3	6	12			
	Toop Cover Assembly	20	2251001P0260	9608S-26A-G2C	4	12	24	48			
	Toop Cover Assembly	-	41733701	Gear-Inner	2	6	12	24	ECO-C7400-		
	Toop Cover Assembly	-	41778001	Gear-Inner	2	6	12	24	ECO-C7400-		
	Printer Unit Chasssis	1	41189701	Drum contact assembly	4	12	24	48			
	Printer Unit Chasssis	2	40844301	Roller-Assy Regist A	1	3	6	12			
	Printer Unit Chasssis	3	40844303	Roller-Assy Regist B	1	3	6	12			
	Printer Unit Chasssis	4	40845401	Gear-RE3	1	3	6	12			
	Printer Unit Chasssis	5	41187101	Gear-Assy Clutch	1	3	6	12			
	Printer Unit Chasssis	6	40845801	Motor-Assy Regist	1	3	6	12			
	Printer Unit Chasssis	7	PB4076-5290P001	Motor-Fan(92)	1	3	6	12			
	Printer Unit Chasssis	8	41346801	Sensor Assy.-Regist	1	3	6	12			
	Printer Unit Chasssis	9	41253701	Magnet Assy Shatter	1	3	6	12			
	Printer Unit Chasssis	10	41275201	Plate-Shutter	1	3	6	12			
	Printer Unit Chasssis	11	41275301	Spring-Coil	1	3	6	12			
	Printer Unit Chasssis	12	40859201	Guide Assy.-Dup	1	3	6	12			
	Printer Unit Chasssis	13	40841101	Printer Unit Chassis	1	3	6	12			

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000			
	Printer Unit Chasssis	14	41312801	Plate Assy Damper(L)	1	3	6	12			
	Printer Unit Chasssis	15	41312901	Plate Assy Damper(R)	1	3	6	12			
	Printer Unit Chasssis	16	40841601	Sensor-Ent1	1	3	6	12			
	Printer Unit Chasssis	17	40841701	Sensor-Ent2	1	3	6	12			
	Printer Unit Chasssis	18	40841801	Sensor-Write	1	3	6	12			
	Printer Unit Chasssis	19	41258301	Board-R71	1	3	6	12			
	Printer Unit Chasssis	21	41253601	Magnet Assy Duplex	1	3	6	12			
	Printer Unit Chasssis	22	40842401	Gear-EXB	2	6	12	24			
	Printer Unit Chasssis	23	40316301	GEAR-Roller(C)	1	3	6	12			
	Printer Unit Chasssis	24	41067201	Gear-EXA	1	3	6	12			
	Printer Unit Chasssis	25	40323901	ROLLER-Feed(C)	1	3	6	12			
	Printer Unit Chasssis	26	PP4076-3949P001	Bush	1	3	6	12			
	Printer Unit Chasssis	27	PP4043-4489P001	Bearing-Feed	1	3	6	12			
	Printer Unit Chasssis	28	40842501	Plate-FG EX	1	3	6	12			
	Printer Unit Chasssis	29	41073601	Sensor Assy.-Exit	1	3	6	12			
	Printer Unit Chasssis	30	40841301	Lever-Lock-Heat L	1	3	6	12			
	Printer Unit Chasssis	31	40841501	Spring-Lock Lever	2	6	12	24			
	Printer Unit Chasssis	32	40848801	Motor-Assy Belt	1	3	6	12			
	Printer Unit Chasssis	33	40841401	Lever-Lock-Heat R	1	3	6	12			
	Printer Unit Chasssis	35	40847301	Motor Assy Main	1	3	6	12			
	Printer Unit Chasssis	36	40846001	Motor-Pulse Feed(42)	1	3	6	12			
	Printer Unit Chasssis	37	40848501	Gear-H1	1	3	6	12			
	Printer Unit Chasssis	38	40848601	Gear-H2	1	3	6	12			
	Printer Unit Chasssis	39	41303601	Plate-Assy L	1	3	6	12			
	Printer Unit Chasssis	40	40850201	Contact Assy	1	3	6	12			
	Printer Unit Chasssis	41	40737501	PWR unit-ACDC Switch(230V)	1	3	6	12			
	Printer Unit Chasssis	41	40737502	PWR unit-ACDC Switch(230V)	1	3	6	12	ECO-C7400-064		
	Printer Unit Chasssis	43	40737601	PWR unit-(high voltage)	1	3	6	12			
	Printer Unit Chasssis	44	2381003P0016	HCUJ/TW-VFH/19F-330	1	3	6	12	ECO-C7400-		
	Printer Unit Chasssis	45	41128101	Sheet-Insulator	1	3	6	12			
	Printer Unit Chasssis	49	41346301	Holder Assy.-Belt Fuse	2	6	12	24			
	Printer Unit Chasssis	50	41469001	Motor-Fan	1	3	6	12			
	Paper Tray Guide	1	40839801	Feeder-Unit Main	1	3	6	12			
	Paper Tray Guide	2	40371301	ROLLER Assy.-Hopping	1	3	6	12			
	Paper Tray Guide	3	40313201	Roller Assy.-Feed	1	3	6	12			
	Paper Tray Guide	4	40325401	Gear-z58	1	3	6	12			
	Paper Tray Guide	5	40839001	Guide Assy.-Cass(L)	1	3	6	12			
	Paper Tray Guide	6	40839401	Guide Assy.-Cass(R)	1	3	6	12			
	Paper Tray Guide	11	40349701	Roller-Link	2	6	12	24			
	Paper Tray Guide	12	40368304	Board-PXC	1	3	6	12			
	Paper Tray Guide	14	PP4076-5360P001	Spring-Detector	1	3	6	12			
	Paper Tray Guide	15	41309101	Tray2 connector Assy	1	3	6	12			
	Paper Tray Guide	16	PB4016-1960P004	RUBBER FOOT	4	12	24	48			
	Paper Tray Guide	21	41275901	Microswitch-Assy	1	3	6	12			
	Duplex Unit	1	41305301	FRAME-Main Assy	1	3	6	12			
	Duplex Unit	6	41372903	PX701 Duplex-Unit-Bulk(OEL)	1	-	-	-	OEL		
	2nd_3rd Tray	1	41304503	Tray-Option(701_OEL/APS)	1	-	-	-	OEL/APS		
	2nd_3rd Tray	2	41780302	Board-V7X	1	3	6	12	ECO-C7400-		
	2nd_3rd Tray	3	41400501	Cover-FrontOP Assy	1	3	6	12	ECO-C7400-		
	2nd_3rd Tray	4	41462301	Option Tray(2) Connector Assy	1	3	6	12			
	2nd_3rd Tray	5	41462201	Option Tray(1) Connector Assy	1	3	6	12			
	2nd_3rd Tray	6	41581101	Spare-Feeder-Drive-Assembly	1	3	6	12			
	2nd_3rd Tray	7	40366501	Motor-	1	3	6	12			
	2nd_3rd Tray	8	41859201	Clutch-MCA26	1	3	6	12	ECO-C7400-		